



# Lorne - Beds

## Product Size Guide



Australian Made,  
Australian Owned.



- Single Bed Head Only
- Single Bed with Doona Foot
- Single Bed with Low Foot
- Single Bed with High Foot

- 1020 W x 1370 H
- 1020 W x 1370 H x 2290 L
- 1020 W x 1370 H x 2290 L
- 1020 W x 1370 H x 2290 L



- King Single Bed Head Only
- King Single Bed with Doona Foot
- King Single Bed with Low Foot
- King Single Bed with High Foot

- 1170 W x 1370 H
- 1170 W x 1370 H x 2290 L
- 1170 W x 1370 H x 2290 L
- 1170 W x 1370 H x 2290 L



- Double Bed Head Only
- Double Bed with Doona Foot
- Double Bed with Low Foot
- Double Bed with High Foot

- 1480 W x 1370 H
- 1480 W x 1370 H x 2290 L
- 1480 W x 1370 H x 2290 L
- 1480 W x 1370 H x 2290 L



- Queen Bed Head Only
- Queen Bed with Doona Foot
- Queen Bed with Low Foot
- Queen Bed with High Foot

- 1630 W x 1370 H
- 1630 W x 1370 H x 2290 L
- 1630 W x 1370 H x 2290 L
- 1630 W x 1370 H x 2290 L



- King Bed Head Only
- King Bed with Doona Foot
- King Bed with Low Foot
- King Bed with High Foot

- 1930 W x 1370 H x 2290 L
- 1930 W x 1370 H x 2290 L
- 1930 W x 1370 H x 2290 L
- 1930 W x 1370 H x 2290 L



- Super King Bed Head Only
- Super King Bed with Doona Foot
- Super King Bed with Low Foot
- Super King Bed with High Foot

- 2140 W x 1370 H x 2290 L
- 2140 W x 1370 H x 2290 L
- 2140 W x 1370 H x 2290 L
- 2140 W x 1370 H x 2290 L

Doona Foot Size - 408 H

Low Foot Size - 718 H

High Foot Size - 958 H

For further information regarding our products, please contact us on:  
(03) 9720 - 1188 or [salesteam@flamingofurniture.com.au](mailto:salesteam@flamingofurniture.com.au)

\*All sizing is measured in mm  
\*Items size subject to change  
\*Icons do not reflect drawer combo

# Lorne - Case Goods

## Product Size Guide



Australian Made,  
Australian Owned.

	<b>2 Drawer, 1 Tray, 1 Lower Shelf Bedside</b>	<b>500 W x 760 H x 450 D</b>
	<b>5 Drawer Tallboy</b>	<b>944 W x 1200 H x 450 D</b>
	<b>6 Drawer Dresser Base</b>	<b>1390 W x 815 H x 450 D</b>
	<b>Standard Dresser Mirror</b>	<b>1065 W x 1055 H</b>
	<b>Footlocker</b>	<b>1305 W x 543 H x 565 D</b>

For further information regarding our  
products, please contact us on:  
(03) 9720 - 1188 or [salesteam@flamingofurniture.com.au](mailto:salesteam@flamingofurniture.com.au)

\*All sizing is measured in mm  
\*Items size subject to change  
\*Icons do not reflect drawer combo