



FLAMINGO FURNITURE

Anti-Tip Fixing Instructions

PARTS

1. 2 X L SHAPE BRACKETS 23MM X 23MM X 1.5MM THICKNESS X 11MM WIDE
2. 1 X PAN HEAD SCREW 8G X 30MM LENGTH **THIS IS FOR WALL STUD
3. 1 X CHIP BOARD SCREW 8G X 30MM LENGTH **THIS IS FOR BACK OF UNIT
4. 1 X CABLE TIE 300MM

INSTRUCTIONS

1. Take Part 1 (1 X L SHAPE BRACKET) and Part 3 (1 X CHIP BOARD SCREW 8G X 30MM LENGTH) and screw into Solid part on the back of the furniture, approximately 30mm from top of unit.




Thank you for purchasing our products and supporting Australian Made Timber Furniture. Please review us on google and follow our socials!

 Flamingo Furniture  @flamingofurniture

2. Locate the Wall stud and Take Part 1 (1 X L SHAPE BRACKET) and Part 2 (1 X PAN HEAD SCREW 8G X 30MM LENGTH) and screw bracket into Wall Stud.



3. Thread Part 4 (1 X CABLE TIE 300MM) through both openings on L shape Bracket that you already have fixed to furniture and wall, Pull until Cable tie is secure



WARNING

THIS PRODUCT IS NOT A SUBSTITUTE FOR ADULT SUPERVISION. DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE. NEVER LEAVE YOUR CHILD UNATTENDED

Thank you for purchasing our products and supporting Australian Made Timber Furniture. Please review us on google and follow our socials!

 Flamingo Furniture  @flamingofurniture




FLAMINGO FURNITURE

Anti-Tipping Parts

2 X L SHAPE BRACKETS 23MM X
23MM X 1.5MM THICKNESS X 11MM
WIDE



1 X PAN HEAD SCREW 8G X 30MM
LENGTH **THIS IS FOR WALL
STUD



1 X CHIP BOARD SCREW 8G X
30MM LENGTH **THIS IS FOR
BACK OF UNIT



1 X CABLE TIE 300MM



Thank you for purchasing our products and supporting Australian Made Timber Furniture. Please review us on google and follow our socials!

 Flamingo Furniture  @flamingofurniture